



STARLINK | PERFORMANCE FLAT MOUNT



What's in the Box



Flat Mount



M6 Machine Screws
(4x)



M6 Flat Head Screws
(4x)




M6 Lock Nuts
(4x)



4mm
Hex Key

Recommended Tools



Drill / Impact Driver




6 mm (1/4 in)
Drill Bit



Socket
10mm




Wrench
10 mm






1 | Download the Starlink App

Scan the QR code to download the Starlink App.




2 | Find Mounting Location

Your Starlink needs a clear view of the sky so it can stay connected with satellites as they move overhead. Objects that obstruct the connection between your Starlink and the satellite will cause service interruptions. Use the obstructions tool in your App to ensure you have selected a suitable mounting location.



3 | Install Mount Onto Starlink


Install the provided 16mm bolts through the mount into the back of the Starlink. Tighten the four bolts using the hex key to lock the Flat Mount in place. Tighten screws in all 4 corners until bolts reach 7 Nm (5.2 lb-ft). Ensure the mount is firmly attached to the Starlink.



4 | Mark Mounting Holes

Using the Flat Mount as a template, mark the four mounting holes on the desired mounting location using a pen or pencil.


The included machine screws can accommodate mounting surfaces up to 19mm (3/4") thick.



5 | Drill the Pilot Holes

Drill the holes with a 7 mm (9/32 in) drill bit.


Remove burrs around holes and make sure the surface is free of debris.



6 | Plug in Starlink Cable

Align the Performance connector end of the Starlink cable indicated by the red notch and plug into your Starlink by holding the end of the plug and firmly inserting into the dish.

If the Starlink cable needs to be removed, rotate the collar counterclockwise and pull to disconnect from your Starlink.



7 | Install Screws

Install the 4 35mm machine screws into the pre-drilled holes using a 10mm socket end wrench. Tighten screws in all 4 corners until bolts reach 8 Nm (5.9 lb-ft).

